



Polaroid

Parts Catalog

ID-3000

January 1993

TO ORDER PARTS, CONTACT:

Polaroid Corporation
Parts Logistics Department
201 Burlington Road
Bedford MA 01730
TEL: 1.800.343.4846
FAX: 1.781.386.5606

Give PART NUMBER, full PART NAME, and QUANTITY desired. Merchandise returns accepted only upon written authorization. Parts carry a replacement warranty for 90 days from date of purchase.

Americas Business Center
Technical Services
TEL: 1.781.386.5309
FAX: 1.781.386.5988


ID-3000

DIGITAL SECURITY & IDENTIFICATION SYSTEM PARTS CATALOG

TABLE OF CONTENTS

Description	Plate No./Parts List No.
ID-3000T SYSTEM (with Color Thermal Printer)	1
ID-3000F SYSTEM (with Color Film Recorder)	2
COMPUTER	3
COLOR PORTRAIT CAMERA AND STROBE	4
ID-3000F SYSTEM CABLES	5
ID-3000T SYSTEM CABLES	6
COLOR FILM RECORDER AND POWER SUPPLY ASSEMBLY	7
COLOR FILM RECORDER (CI-5000) COMPONENTS	
MAIN ASSEMBLY	8
CHASSIS COMPONENTS	9
CABLES	10
CAMERA BACK, 1.7 MAGNIFICATION	11
THERMAL PRINTER REAR HOUSING, CHASSIS ADAPTER AND COMPONENTS	12
TX-1500 THERMAL PRINTER COMPONENTS	13, 14
SIGNATURE SCANNER ASSEMBLY	15
LAMINATOR (General)	16
LAMINATOR (Detailed)	17
DIE CUTTER	18
ID-3000 VERIFICATION STATION	19
OPTIONAL AND ACCESSORY EQUIPMENT	20


PLATE 1
ID-3000T SYSTEM (with Color Thermal Printer)



PARTS LIST 1
ID-3000T SYSTEM (with Color Thermal Printer)

KEY NO.	PART NO.	PART NAME
1	1B2175A	Camera and Post Assembly
2	1B2028A 1B2029A 1B8397A	HP 13" Color Monitor HP Tilt/Swivel Base HP Monitor Auto Switch with Base
3	1B5470	HP Vectra QS/20 386 Computer (Complete with Board Assemblies)
4	-	Keyboards:
	1B0302G	U.S.
	1B0302D	French
	1B0302B	German
	1B0302C	Spanish
		Japanese
	1B0302F	U.K.
	1B0302E	Italian
	1B0302A	French Canadian
5	1B1150C	Thermal Color Printer Assembly
6	6165640 TBD	Laminator (115V Model 5000T for 3000T System) Laminator (220V Model 5000T for 3000T System)
7	1B2066A	External Signature Scanner Assembly
8	6173180	Polaroid Color Scanner (CS500I)
9	1A6190A	Modem 2400EX
10	6169960 6169940 6169920	Die Cutter, 1-Up, CR-80 Die Cutter, 1-Up, CR-79 Die Cutter, 2-Up, CR-60
(Not Shown)	1B2191A	Camera Support Backplate


PLATE 2
ID-3000F SYSTEM (with Color Film Recorder)



PARTS LIST 2
ID-3000F SYSTEM (With Color Film Recorder)

KEY NO.	PART NO.	PART NAME
1	1B2175A	Camera and Post Assembly
2	1B2028A 1B2029A 1B8397A	HP 13" Color Monitor HP Tilt/Swivel Base HP Monitor Auto Switch with Base
3	1B5470A	HP Vectra QS/20 386 Computer (Complete with Board Assemblies)
4	-	Keyboards:
	1B0302G	U.S.
	1B0302D	French
	1B0302B	German
	1B0302C	Spanish
		Japanese
	1B0302F	U.K.
	1B0302E	Italian
	1B0302A	French Canadian
5	6169950 6169940 6169910	Die Cutter, 1-Up, CR-80 Die Cutter, 1-Up, CR-79 Die Cutter, 2-Up, CR-60
6	6169900 6173940	Laminator (115V Model 2100 for 3000F System) Laminator (220V Model 2200 for 3000F System)
7	1B6133C	Color Film Recorder Assembly
8	787771C	Camera Back, 1.78 Magnification
9	1B2066C	External Signature Scanner Assembly
10	6173180	Polaroid Color Scanner (CS500I)
11	1A6190A	Modem 2400EX


PLATE 3
HP VECTRA QS/20 386 COMPUTER



PARTS LIST 3
HP VECTRA QS/20 386 COMPUTER

KEY NO.	PART NO.	PART NAME
-	1D5470A	HP Vectra QS/20 Computer and Board Assembly
-	1A9852A	HP Vectra QS/20 386 Computer
1	1A9858A	Hard Drive, 48 MB
	1D5468A	Hard Drive, 120 MB
	1B0734A	Adapter Kit for 48 and 120 MB Hard Drives
	1A6244A	Hard Drive, 85 MB
	1A6479A	Hard Drive, 180 MB
	TBD	Hard Drive, 240 MB
	1A9859A	Hard Drive, 340 MB
	1D5483A	Hard Drive, 760 MB
2	1B0274A	Viper Tape Drive, 150/250 MB
	1A9851A	Cartridge, 150 MB
	1A9851B	Cartridge, 250 MB
	1D5482A	Viper Tape Drive, 525 MB
	1D5484A	Cartridge, 525 MB
3	0950-2103	Floppy Drive, 5.25", 1.2 MB
	1D5202A	Combo Floppy Drive
4	-	PC Boards (Slot Number Shown in []):
	1A9826A	DSP Board [S4]
	1A9945A	AST I/O Mini Board [S5]
	1A9939A	Serial Comm. Bd. (Digiboard) [S5]
	1B0743B	Matrox Illuminator 16/AT/2M [S1]
	1B2150A	Support Board Assembly [S3]
	1B2179A	Paradise VGA 1024 x 256K Board [S2]
	1A6469A	885 SCSI Controller Board [S6]
	1B8355A	885MSCSI Controller Board [S6]
	D1410-60001	HP CPU Board with 4 MB RAM [S8]
	1A4502A	Comm 2 Adapter used W/AST I/O Board
5	0950-2190	Power Supply
6	-	Alpha Cable (Included with Illuminator Board)
-	45935-60201	Battery Assembly
-	1A9951A	Rail Set


PLATE 4
COLOR PORTRAIT CAMERA AND STROBE



PARTS LIST 4
 COLOR PORTRAIT CAMERA AND STROBE

KEY NO.	PART NO.	PARTNAME
1	1A6659A	JVC Camera TK-870U
2	1D5220A	Camera Strobe Bracket (Universal)
3	1A5907A 1A9944A	Auto Iris Lens - 25mm (Optional) Auto Iris Lens - 16mm (Standard)
4	1B0377B	ID-3000 Strobe
5	1B0730A	Microfluid Head
6	1B2159A	Cable Assembly, Camera and Strobe
(Not Shown)	1A6173A	Accessory Shoe Spring
(Not Shown)	1A6171A	Accessory Shoe Rework
(Not Shown)	179701A	Screw (3)


PLATE 5
ID-3000F SYSTEM CABLES



PARTS LIST 5
ID-3000FSYSTEM CABLES

KEY NO.	PART NO.	PARTNAME
1	1A6463A	Modem Cable (25 to 9 pin)
2	1B2172A 1B0351A	SCSICable MAC SCSI Cable (Used on Universal ID-3000 Only)
3	1B2174A	SupportBoard Cable
4	1B2801A	Capture Cable
5	1B0820A	AC Power Cord
6	797377A	Power Outlet Strip, 110 VAC
7	1A6748A	SCSITerminator
8	1B8811B	Video Breakout Cable (Used with B/W Thermal Printer Only)
9	5S0011001	CS-500SCSI Cable
(Not Shown)	1B2778A	Digi Cable (Optional - Used with Digi Board Only)
(Not Shown)	1A6438A	Modem Cable


PLATE 6
ID-3000T SYSTEM CABLES



PARTS LIST 6
ID-3000T SYSTEM CABLES

KEY NO.	PART NO.	PARTNAME
1	1A6463A	Modem Cable
2	1D5480A	TX-1500 VGA Cable, Male
3	1B2174A	Support Board Cable
4	1D5480B	TX-1500 VGA Cable, Female
5	1B0820A	AC Power Cord
6	797377A	Power Outlet Strip, 110 VAC
7	1D5466A	Capture Cable
8	5D00 30001	Apple SCSI Terminator (Used on Universal ID-3000 Only)
9	5S0011001	CS-500SCSI Cable
(Not Shown)	1B2778A	Digi Cable


PLATE 7
COLOR FILM RECORDER AND POWER SUPPLY ASSEMBLY



PARTS LIST 7
COLOR FILM RECORDER AND POWER SUPPLY ASSEMBLY

KEY NO.	PART NO.	PART NAME
1	1B2647A	Timer Board
2	1A4567A	Power Supply
3	1B2772A	Cable Assembly 6V PS AC Input
4	1B2775A	Output Fan Assembly
5	1A5694A	SCSI Board Assembly
6	1D3388A	Camera/Support Interface Board
7	1A3983D	34-Pin Ribbon Cable Assembly
8	791507A	Power Entrance Module (6VMIS)
9	CPA0086	Color Film Recorder Final Assembly
10	(See Plate 15)	Signature Scanner Assembly
11	1D3390A	Back Panel
-	1B0434A	Cover


PLATE 8
CI-5000 COLOR FILM RECORDER MAIN ASSEMBLY



PARTS LIST 8
CI-5000 COLOR FILM RECORDER MAIN ASSEMBLY

KEY NO.	PART NO.	PARTNAME
1	761405L	Front Housing
2	770987A	LEDHolder
3	768431G	E-ring,Filter Wheel Pivot
4	761491B	Filter Wheel Assembly
5	761752A	Pivot,Filter Wheel
6	768117C	KepsNut, #4-40 (Filter Wheel Pivot)
7	800083-404	Button Head Capscrew, SS, 10-24 x .625"
8	800016-301	Split washer, #10, SS
9	800158-135	Flat washer, #10, SS
10	766374C	Bumper (Rubber Foot)


PLATE 9
CI-5000 COLOR FILM RECORDER CHASSIS COMPONENTS



PARTS LIST 9
CI-5000 COLOR FILM RECORDER CHASSIS COMPONENTS

KEY NO.	PART NO.	PART NAME
1	1A6458A	Light Shield
2	768211B	Flat Washer
3	703141D	Lockwasher
4	743040M	Screw
4A	743040F	Screw
5	1A4567A	Switching Power Supply (Conv. Concepts)
6	735871C	Phillips Pan Head Screw, 6-32 x .25"
7	770355A	Spacer, M/F, 6-32 x .25" Hex
8	735306A	Star Washer, #6 Internal Tooth
9	768117C	Keps Nut 6-32
10	1A3651A	Blank Panel (Centronics)
11	735306A	Star Washer, #6 Internal Tooth
12	735871C	Phillips Pan Head Screw, 6-32 x .25"
13	703312O	Oval Head Pop Rivet, .318" Long
14	766642B	Line Filter Assembly
15	735306A	Star Washer, #6 Internal Tooth
16	735871C	Phillips Pan Head Screw, 6-32 x .25"
17	209895D	Nut
18	735306A	Star Washer, #6 Internal Tooth
19	770355A	Spacer, M/F, 6-32 x .25"
20	1A5631A	Monitor Board
21	1A3513A	Chassis Weldment
22	735871D	Phillips Pan Head Screw, 6-32 x .375"
23	768431G	E-ring
24	768117A	Nut
25	185729D	Terminal Lug, Shakeproof #6
26	715698A	Pick Return Spring
27	768094C	Stepper Motor and Cable Assembly
28	761493C	Monitor Support
29	766094A	Monitor Clamp (2)
30	743040M	Cap Screw, Socket Head, 8-32 x 1.375" L (2)
31	883722C	CRT and Yoke Assembly
32	766457A	Fastener, U-type, 8-32
33	768103A	Shim, Left Side, 0.005" (As required.)
33	768103B	Shim, Left Side, 0.010" (As required.)
33	768103C	Shim, Left Side, 0.020" (As required.)
33	768104A	Shim, Right Side, 0.005" (As required.)
33	768104B	Shim, Right Side, 0.010" (As required.)
33	768104C	Shim, Right Side, 0.020" (As required.)


PLATE 9 (Con't)
CI-5000 COLOR FILM RECORDER CHASSIS COMPONENTS



PARTS LIST 9 (Con't)
CI-5000 COLOR FILM RECORDER CHASSIS COMPONENTS

KEY NO.	PART NO.	PART NAME
34	735306A	Star Washer, #6 Internal Tooth
35	735871C	Phillips Pan Head Screw, 6-32 x .250"
36	1A4787C	Chassis Back Plate
37	1A3814B	Logic Board Assembly, CI-5000
38	701705B	Star Washer, #6 Internal Tooth
39	735871C	Phillips Pan Head Screw, 6-32 x .250"
40	1B2118A	Memory Daughter Board, 4MB


PLATE 10
CI-5000 COLORFILM RECORDER CABLES



PARTS LIST 10
CI-5000 COLORFILM RECORDER CABLES

KEY NO.	PART NO.	PART NAME
1	1A3882A	Camera Cable Assembly (DIN to Logic Board)
2	761250C	Wheel Position Cable Assembly
3	768094C	Stepper Motor Cable Assembly
4	1A5556A	Centronics Parallel Cable
5	1A5571A	Photocell and Wire Assembly
6	1A3878A	Power Cable Assembly (Line Filter to Power Switch)
7	1A3880B	Power Supply Cable Assembly (Power Switch to Power Supply)
8	1A5543A	Power Indicator LED (Green) and Cable Assembly
9	1A3884A	DC Power Cable (Power Supply to Logic Board)
-	1A3881A	Ground Wire Assembly (Power Supply Ground Cable; Not Shown)

PLATE 11
CI-5000 COLOR FILM RECORDER CAMERA BACK




PARTS LIST 11
CI-5000 COLOR FILM RECORDER CAMERA BACK


KEY NO.	PART NO.	PART NAME
-	787771C	Camera Back, 1.78 Magnification
1	794700A	Cable Assembly, Camera Back
2	703116O	Screw (for Switch) (2)
3	766298B	Mirror
4	766296C	Mirror Retainer
5	743459D	Screws for Key #5 (2)
6	155164B	Washer for Key #6 (2)
7	718452B	Interlock Switch
8	155164B	Washer for Key #3 (2)
9	735309A	Nut for Key #3 (2)
10	796053A	Light Seal
11	794747A	1-Up Lens Assembly
12	768142A	Sleeve Cap 108 (2)
13	766783A	Thumbscrew (2)
14	766990A	Lens Cap
15	794866A	Spacer, 0.060"
15	794866B	Spacer, 0.120"
16	735179D	Screw (8)
17	794739A	Switch Pin
18	758948C	Film Holder CB-1030

PLATE 12
THERMAL PRINTER REAR HOUSING, CHASSIS ADAPTER AND COMPONENTS

Non-Interlace Unit



Interlace Unit




PARTS LIST 12
THERMAL PRINTER REAR HOUSING, CHASSIS ADAPTER AND COMPONENTS

KEY NO.	PART NO.	PART NAME
1	1B1167A	Chassis Adapter
2	1B2807A	Cable Assembly DIN Pin
3	791507A	Power Entry Module
4	1D3388A	Camera/Support Interface Board
5	1B2772A	Power Supply/Strobe Cable
6	1D3389A	Housing Component
7	1B2806A	Cable Assembly DM15M (Non-Interlace Only)
8	1A4567A	Power Supply
9	1B8392A	TX 1500 Rework Printer
10	1D5464A	Cable Assembly (Interlace Only)
11	1D5465A	Cable Assembly (Interlace Only)

PARTS LIST 13
TX-1500COLOR THERMAL PRINTER COMPONENTS

KEY NO.	PART NO.	PART NAME
1	8744406	Bind Screw, 377D x 6MM
2	6006064	Top Cover
3	8678406	DT Screw, 4MMD x 6MM (Black)
4	8741405	Bind Screw, 3MMD x 5MM
5	6527221	Spring
6	7498051	Plate, Shield
7	7482163	Plate, Shield
8	1611722	Analog PC Board
9	(Not Stocked)	Plate Shield
10	1611681	System PC Board
11	1607612	Memory PC Board
12	5571633	Motor
13	8813114	Spring Washer, 3MMD
14	8744430	Screw, 3 x 30
15	7744502	Spacer
16	6006072	Plate, Rear
17	1607281	Rear Jack PC Board
18	(Not Stocked)	Front Sub PC Board
19	6714213	Nylon Rivet
20	6182781	Frame, PWB
21	(Not Stocked)	Front PC Board
22	6070532	Knob
23	(Not Stocked)	Knob
24	6801841	Band
25	5273762	Switching Regulator, 110V
	5273553	Switching Regulator, 220V
26	6895191	Leg
27	(Not Stocked)	Chassis
28	(Not Stocked)	Chassis
29	(Not Stocked)	Jack PC Board
30	8741405	Bind Screw, 3MMD x 5MM
31	6347641	Damp Unit
32	6527471	Spring
33	8699408	Screw
34	6483642	Front Panel
35	8699412	Screw, 3 x 12 (Black)
36	6407561	Ruch
37	6483402	Ink Door
38	6072262	Button
39	6483412	Paper Door
40	7701161	Sheet


PLATE 13 (Con't)
TX-1500 COLOR THERMAL PRINTER COMPONENTS



PARTS LIST 13 (Cont)
TX-1500 COLOR THERMAL PRINTER COMPONENTS

KEY NO.	PART NO.	PART NAME
41	6029961	Paper Holder
42	7793182	Plate
43	6012883	Case
44	6029982	Case
45	7793171	Cassette Plate
46	(Not Stocked)	Power Switch PC Board
47	6029952	Paper Tray
48	8691408	Screw, 3 x 8
49	(Not Stocked)	Buzzer PC Board
50	6808332	Cover
51	(Not Stocked)	Tray Switch PC Board
52	8741108	Screw, 2 x 8
53	1607281	Mechanical Sensor PC Board
54	1604121	Wiring PC Board


PLATE 14
TX-1500COLOR THERMAL PRINTER COMPONENTS



PARTS LIST 14
TX-1500COLOR THERMAL PRINTER COMPONENTS

KEY NO.	PART NO.	PART NAME
1	6781792	Arm
2	7778859	Polyslider Washer
3	0741303	Bind screw, 2.6MMD x 3MM
4	7774942	E-ring
5	7786112	Polyslider Washer
6	6300843	Spring
7	7367151	Slider
8	6551831	Spring
9	6781462	Arm
10	0711304	Pan Head Screw, 2.6MMD x 4MM
11	5475213	PWB Assembly, Ink Jam Sensor
12	7367161	Slider
13	5625091	Slide Switch
14	5959043	PWB Assembly, Mode Switch/End Sensor
15	0711306	Pan Head Screw, 2.6MMD x 6MM
16	6870752	Worm Drive
17	5575751	Motor
18	6782053	Idler Gear
19	6782042	Gear
20	6781482	Gear
21	6781471	Ring
22	6781971	Gear
23	6302731	Spring
24	7774943	E-ring
25	7787412	Washer
26	6782031	Gear
27	6781431	Arm
28	6433961	Gear
29	6895173	Gear
30	6347581	Gear
31	7783901	Screw
32	7781712	SP Screw, 3MMD x 5MM
33	(Not Stocked)	Chassis (L)
34	1605382	PWB Assembly, Paper Sensor
35	7366912	Head Arm


PLATE 14 (Con't)
TX-1500 COLOR THERMAL PRINTER COMPONENTS



PARTS LIST 14 (Cont)
TX-1500 COLOR THERMAL PRINTER COMPONENTS

KEY NO.	PART NO.	PART NAME
36	8671404	DT Bind Screw, 3MMD x 4MM
37	6782083	Lever
38	4505893	Roller
39	7453933	Sheet
40	6538842	Spring
41	7368722	Arm
42	5446662	Head
43	7230902	E-ring for Pause Slider Plate
44	7230901	E-ring for Spring Mounting
45	6782104	Arm
46	6538833	Spring
47	7786119	Polyester Washer
48	8741403	Bind Screw, 3MMD x 3MM
49	6378221	Plate
50	6561431	Cushion
51	-	Plate
52	7429613	Plate
53	1605371	PWB Assembly, Ink Select Sensor
54	8813114	Spring Washer, 3MMD
55	8812114	Washer, 3MMD Small
56	8741406	Screw, 3 x 6
57	(Not Stocked)	Holder
58	6539694	Spring
59	6782063	Slider
60	7453933	Sheet
61	5477362	PWB Assembly, Ink Cassette Switch
62	8741108	Screw, 2 x 8
63	6539702	Spring
64	4506441	Shaft
65	4505901	Shaft
66	7368381	Spring
67	6781662	Roller, Pressure
68	7132662	Chassis (R)
69	6895182	Cam (R)
70	7368576	Slider


PLATE 14 (Con't)
TX-1500 COLOR THERMAL PRINTER COMPONENTS



PARTS LIST 14 (Con't)
TX-1500 COLOR THERMAL PRINTER COMPONENTS

KEY NO.	PART NO.	PART NAME
71	7787933	Washer
72	6538851	Spring
73	6781691	Lever
74	7789301	Washer
75	6782131	Bearing
76	6384161	Drum
77	6781707	Block
78	7410531	Spring
79	6781662	Roller, Pressure
80	7787611	Polyester Slider Washer
81	7739004	Sheet
82	5475011	Paper Sensor CBA
83	7368391	Spring
84	7050023	Paper Supply Mechanism
85	7368553	Idler
86	7368545	Roller
87	6357661	Belt
88	7369811	Arm
89	6539791	Spring
90	5477493	PWB Assembly, Paper Jam Sensor
91	6781884	Roller
92	6781931	Arm
93	6424161	Roller
94	6357671	Belt
95	7787738	Polyslider Washer
96	6433991	Gear
97	(Not Stocked)	Holder, PC Board
98	6424151	Roller
99	(Not Stocked)	Plate
100	6424171	Roller


PLATE 15
SIGNATURE SCANNER ASSEMBLY



PARTS LIST 15
SIGNATURE SCANNER ASSEMBLY

KEY NO.	PART NO.	PART NAME
1	1A7554B	Card Guide Plate
2	1B1153A	Card Guide Bezel
3	1B6148A	Scanner (32 Logitech)
4	1B8283A	DC Motor (S-161B)
5	1B8857A	Scanner Motor Cable
6	1B8255A	Motor Driver Interface PCB
7	1B6850A	Photointerrupt Cable Assembly
8	1D5253A	Power I/O Cable, External Scanner
(Not Shown)	1B8861A	Cable, External Scanner (Connects Scanner Board to Support Board)
(Not Shown)	1D4239A	Power and I/O Scanner Cable Assembly (5 pin to 5 pin)
(Not Shown)	1D4240A	Scanner Cable Assembly (8 pin to 8 pin)

PLATE 16
LAMINATOR (GENERAL)




PARTS LIST 16
LAMINATOR (GENERAL)

Model 2100 115VAC, for ID-3000F System — PID No. 616990*
 Model 2200 220VAC, for ID-3000F System — PID No. TBD *
 Model 5000T 115VAC, for ID-3000T System — PID No. 616564*

KEY NO.	PART NO.	PART NAME
1	5056	Exit Table Assembly
2	5888	Heater Shield
3	791508A	Cover, Left Hand
4	8128	Screw, 6-32 x 1-7/16 Flat Head Phillips
5	5808-1 5809-1	Front Panel, Model 2100 (115VAC) Front Panel, Model 2200 (220VAC)
6	766362B	Line Filter EMI Corcomp 3EDI
7	791584A	Pedestal
8	8019	Screw, 6-32 x 5/16 Round Head Phillips
9	794557A	Foot (4) SJ-5012 Gray
10	7798161A	Label., Product ID (Model 2100)
11	791509A	Cover, Right-Hand
12	8902	Screw, 6-32 x 3/8 Round Head Phillips
13	8089	Screw, Shoulder 10-32 x 1/4
14	8911	Screw, #8 x 3/4 Plastilok
(Not Shown)	794392A	Power Cord, Model 2100 115VAC
(Not Shown)	791911A	Power Cord, Model 2200 220VAC
(Not Shown)	5852	Packaging, Box Assembly


PLATE 17
LAMINATOR (DETAILED)



PARTS LIST 17
LAMINATOR (DETAILED)

KEY NO.	PART NO.		PART NAME
	MODEL 2100	MODEL 2200	
1	797237A	1A3797A	Circuit Board Assembly
2	8019	8019	Screw, 6-32 x 5/16 RH Phil, MS
3	797359A	797409A	Motor, Autotrol
4	8113	8113	Washer, .010 x .250 x .500
5	5019	5019	Upper Roller Assembly (2)
6	5012	5012	Lower Roller Assembly (2)
7	5048-1	5097-1	Heater Assembly
8	8190	8190	Screw, Shoulder 10-32
9	8119	8119	Washer, Plastic
10	8112	8112	Screw, Shoulder 6-32 x 9/16 PH "F"
11	7052-3	7052-4	Thermometer
12	5103	5103	Spring, Thermometer
13	5006-9	5006-9	Bearing Bracket Assembly
14	8910	8910	Screw, Plastic #6 x 3/4
15	794824A	794824A	Guide Bracket
16	797247A	797247A	Optical Sensor Pair W/Cable
17	5102	5102	Extension Spring
18	5011	5011	Entry Table
19	794823A	794823A	Interrupter Bracket
20	8120	8120	Screw, MS Type 23, 8-32 x 1/2
21	5801-8	5801-8	Slide Frame, Right Side
22	7229	-	Polaroid Switch, 115V
	-	7233	Polaroid Switch, 230V (Green)
	-	7233-1	Polaroid Switch, 230V (Amber)
23	7157	5857	Fuseholder Assembly
24	7003	-	Fuse 3A 250V
	-	7001	Fuse 5 x 20mm 1.6A
25	8102	8102	Rivet, Tubular 1/8 x 15/64
26	8160	8160	Grommet 0-1-NBR
27	8902	8902	Screw, 6-32 x 3/8
28	8045	8045	Lockwasher, #6 Internal Tooth
29	8033	8033	Washer, #10 x .032
30	8115	8115	Washer, #10 x .120
31	7113	7113	Drive Gear
32	7113-1	7113-1	Idler Gear
33	8060	8060	Screw, Shoulder 10-32 x .875 PH #2
34	8114	8114	E-clip Retainer
35	8010	8010	Screw, 6-32 x 3/8
36	5801-9	5801-9	Side Frame, Left Side
37	8148	8148	Support Spacer, Hex (3)


PLATE 18
DIECUTTER



PARTS LIST 18
DIECUTTER

KEY NO.	PART NO.	PARTNAME
-	616995	Die Cutter, ID-3000F, 1-up, CR-80
-	616993	Die Cutter, ID-3000F, 1-up, CR-79
-	616991	Die Cutter, ID-3000F, 2-up, CR-60
-	616996	Die Cutter, ID-3000T, 1-up, CR-80
-	616994	Die Cutter, ID-3000T, 1-up, CR-79
-	616992	Die Cutter, ID-3000T, 2-up, CR-60
1	(Part of Key #7)	Arm Ball
2	794657A	Cover Assembly, CR-79
	TBD	Cover Assembly, 2-UP
	TBD	Cover Assembly, CR-80
3	794207A	Pin
4	794188A	Punch, CR-79
	TBD	Punch, 2-UP
	TBD	Punch, CR-80
5	796022A	Punch Mount Assembly
6	794558A	Spring, Punch Mount (4)
7	791806A	Arm Handle
8	796021A	Cam Return Pin
9	794560A	Bushing Retainer
10	794737A	Bushing Guide
11	791817A	Pivot Shaft
12	794562A	Pivot Bushing
13	791585	Base
14	735181E	Screw, Taptite #8-32Y150 (8)
15	796019A	Foot (4)
16	794561A	Cam Pin
17	794556A	Rubber Stop
18	794054A	Die Cutter Cam
19	716449	Screw, Socket Head 1/4-20x.75 (2 or 4)
20	794192A	Die Plate, CR-79
	TBD	Die Plate, 2-UP
	TBD	Die Plate, CR-80
21	700348A	Screw, Buttom Head, Socket, 1/4-20 x .75 (4)

PLATE 19
ID-3000 VERIFICATION STATION
(HP Vectra QS/20 386 Computer)



PARTS LIST 19
 ID-3000 VERIFICATION STATION
 (HP Vectra QS/20 386 Computer)

KEY NO.	PART NO.	PART NAME	
1	1B2028A	HP 13" Color Monitor	
	1B2029A	HP Tilt/Swivel Base	
	1B8397A	HP Monitor Auto Switch with Base	
2	1A9852A	HP Vectra QS/20 386 Computer	
3	794268A	Keyboard (English)	
4	1A4936A	Alpha Cable (Connects S5 and S6)	
5	-	PC Boards (Slot Number Shown in []):	
	1A9826A	DSP Board	[S3]
	1A9945A	AST I/O Mini Board	[S4]
	1B0743B	Matrox Illuminator 16/AT/2M (For Advanced VS Only)	[S6]
	1B2179A	Paradise VGA 1024 x 256K Board	[S5]
	1A3793A	Split Screen Board (For Standard VS Only)	[S6]
	1A6469A	885 SCSI Controller Board	[S7]
	1B8355A	885M SCSI Controller Board	[S7]
	D1410-60001	HPCPU Board with 4MB RAM	[S8]
6	1A4918A	Terminator, VGA (Used with Standard VS Only)	
7	1A9858A	Hard Drive, 48 MB	
	1A6244A	Hard Drive, 85 MB	
	1D5468A	Hard Drive, 120 MB	
	1A6479A	Hard Drive, 180 MB	
	TBD	Hard Drive, 240 MB	
	1A9859A	Hard Drive, 340 MB	
	1D5483A	Hard Drive, 760 MB	
8	1B0274A	Viper Tape Drive, 150/250 MB	
	1A9851A	Cartridge, 150 MB	
	1A9851B	Cartridge, 250 MB	
	1D5482A	Viper Tape Drive, 525 MB	
	1D5484A	Cartridge, 525 MB	
9	0950-2103	Floppy Drive, 5.25", 1.2 MB	
	1D5202A	Combo Floppy Drive	
-	1A9951A	Rail Set	

PARTS LIST 20
ID-3000 OPTIONAL EQUIPMENT AND ACCESSORIES

KEY NO.	PART NO.	PART NAME
-	1A6277A	Carbon Copy
-	614844	Report Writer
-	1A9941A	QEMM
-	1A9849A	SYTOS Tape Software
-	1A9951A	Rail Set
-	1B0281A	Port Adapter (25 pin to 9 pin)
-	1A6237A	UPS 600V/400W att
-	1A6021A	Copy Stand
-	1A6019A	Copy Stand Lens
-	1A3890A	Copy Stand Cable
-	1A6044A	Copy Stand Cable
-	1A6466B	Printer, Laser Jet HP III
-	1A6465A	1MB Memory Board for HP Laser Jet Printer
-	1A5556A	Parallel Printer Cable
-	1A6044A	Still Video Input Cable
-	1B2008A	Still Video Battery Charger
-	1B2010A	Still Video Disks, 2", Box of 10
-	1B2011A	Still Video Player
-	1B2012A	Still Video Camera
-	1B2013A	Still Video Time Base Corrector
-	1B2025A	Still Video BNC to RCA Adapter
-	1B2024A	Still Video BNC to BNC Cable
-	1A6705A	Barcode Label Printer 3000A 110VAC
-	1A6705B	Barcode Label Printer 3000A 220VAC
-	1A6704A	Barcode Label Printer Ribbon
-	1A6701A	Barcode Label Printer Cable (INTERMEG)
-	1A6703A	Barcode Printer 2" x 5' TTR Tag (7pt)
-	1A6703B	Barcode Printer 1" x 2" TTR Paper Tag
-	1A6703C	Barcode Printer 2" x 5" TTR Labels KIMDURA
-	1A6703D	Barcode Printer 1.9" x 2" TTR Labels KIMDURA
-	1A6703E	Barcode Printer 1.25" x 3" TTR Labels - 2 Mil Poly
-	1A6703F	Barcode Printer 1" x 2" TTR Labels - 2 Mil Poly
-	1A6703G	Barcode Printer 2" x Continuous TTR Labels - Paper
-	1A6703H	Barcode Printer 2" x 5" TTR Labels - Paper
-	1A6703J	Barcode Printer 2" x 4" TTR Labels - Paper
-	1A6703K	Barcode Printer 2" x 3" TTR Labels - Paper
-	1A6703L	Barcode Printer 2" x 1" TTR Labels - Paper

PARTS LIST 20 (Con't)
ID-3000 OPTIONAL EQUIPMENT AND ACCESSORIES

KEY NO.	PART NO.	PART NAME
-	1A6703M	Barcode Printer 1.5" X 0.5" TTR Labels - Paper
-	1A6703N	Barcode Printer 1" X 2.5" TTR Labels - Paper
-	1A6703O	Barcode Printer 0.9" X 3.25" TTR Labels - Paper
-	1A6655A	B/W Thermal Printer, High Resolution (Sony 850)
-	1A9707A	B/W Thermal Printer, Label (Sony 610)
-	1A9708A	Thermal Paper, Sticky T-B90SE, 5 rolls
-	1A6656A	Thermal Paper, Type 110 HD, 5 rolls
-	1A6149A	Thermal Paper, Type 110 Std, 12 rolls
-	1B8811B	Video Breakout Cable
-	1D3395A	MAG Stripe Encoder
-	614831	Dot Matrix Printer
-	1B8393A	Token Ring LAN (NIM) Board
-	1B8357A	Ethernet LAN (NIM) Board
-	TBD	Shiva LAN Modem
-	1B8379A	US Robotics Modem
-	89-2102-000	Avator Modem

PARTS LIST 21
PACKAGING

KEY NO.	PART NO.	PART NAME
-	1B4976A	Signature Scanner Packaging
-	1B4916A	ID-3000Thermal Packaging I/O Unit
-	1B4826A	ID-3000 Camera/Pole Packaging Assembly
-	1B2195A	ID-3000Calibration Target
-	736467A	ID-3000 Shipment Container Bottom
-	736468A	ID-3000 Shipment Container Cover
-	1B4639A	ID-3000Film Shipping Packaging I/O